
DATA SHEET





FHKU G1/4" High Flow

Part number: 938-12xx/xK34x

General Description

The FHKU Flowmeter is a general-purpose device; its working range can be individually defined according to its nozzle size. It is employed for measuring, regulating or metering and guarantees most precise measurement of fluid quantities. In addition, a pulse generator integrated into the flowmeter guarantees a practically unlimited useful life.

Specific applications: Linear inlet and outlet, compact design, great working range, depending on the nozzle diameter. High precision, robust storage, suitably for continuous operation.

Approvals / Standards

EN55014-1:00+A1:01+A2:02, EN61000-6-3:01+A11:04, IEC61000-6-3:06(ed.2.0), EN61000-3-2:06, IEC61000-3-2:05(ed.3.0), EN61000-3-3:95+A1:01+A2:05, IEC61000-3-3:94+A1:01+A2:05(cons.ed 1.2), EN55014-2:97+A1:01, EN61000-6-1:01, IEC61000-6-1:05(ed.2)

Material:

0-ring:

Turbine:

Magnete:

Screws:

Housing: PPS 40%GF Bearing pin: Ceramic

Nozzle: Ø 1.0, 1.2, 2.0, 2.5mm

PPS 40%GF

Nozzle: Ø 3.0, 4.0mm Inox 1.4305 Nozzle: Ø 5.6mm like housing

MVQ (Silikon)

FPM (Viton) / EPDM on request

PVDF 2 Magnets

(4 Magnets on request)

Ceramic Sr Fe O

(not in contact with the medium)

PT-screws Inox A2 (Phillips cross recessed)

Technical data:

Flow rate: from 0.041 l/min
Speed: max. 1900 rpm
Measuring accuracy: +/- 2.0%
Repetition: <+/- 0.25%

Temperature range: -10°C to $+100^{\circ}\text{C}$ 14°F to 212°F

Pressure range: 20 bar at 20°C

290 psi /68°F
Mounting position: Horizontal *

Nozzle size: Ø 1.0, 1.2, 2.0, 2.5, 3.0,

4.0, 5.6mm

Electrical connection ratings:

Power supply: +3.8 to +24 VDC

Consumption: <8 mA

Signal connection: Open collector NPN

Signal voltage: 0 VDC GND

(saturation < 0.7 V)


Signal load: max. 20 mA Leakage current: max. 10 μ A


Connections: 3Pin- AMP 2.8 x 0.8 mm

Signal: Square-wave output

Duty Cycle: ~50%

Dimensions in mm:





Options: 3-pin valve connector Item number: 941-0010/3

We reserve the right to make modifications in the interests of technical progress

RESISTANCE

Special regulations which must be complied with by the flowmeter manufacturer apply to each country, e.g. CE, NSF, FDA and SK. The various media flowing through the flowmeter differ from application to application. You are advised to enquire with the medium manufacturer as to whether the entire installation and the flowmeter are resistant to the medium itself (see Material)!


FIFCTRONIC

DIGMESA electronic circuitry is always designed for operation with DIGMESA flowmeters. Please note the following if connecting to other electronic circuitry:

- The flowmeter does not supply an output voltage but switches the signal terminal to 0 V ground (actuated) or leaves it open (non-actuated)
- ullet There must be a pull-up resistor between power supply + and signal depending on electronic circuitry!


Version 02 FHKU G1/4" High Flow #938-12xx/xK34x GB Seite 2-10


Interface Connection: Examples Open Collector



Digmesa AG, Keltenstrasse 31, CH—2563 Ipsach / Switzerland, Phone +41 (32) 332 77 77, Fax +41 (32) 332 77 88, www.digmesa.com

Measurement Curve FHKU G1/4" Ø1.00mm High Flow





Medium: Water / max. Pressure: 3.3 bar

Number of magnets	Nozzle size	Pulses/ Litres	Gramm/Puls	Recommended min. flow rate at [I/min]	Flow rate at 1900 rpm [l/ min]
2	Ø 1.00 mm	2223	0.45	0.027	0.85
4	Ø 1.00 mm	4446	0.22	0.027	0.85

Part number:

Nozzle Ø 1.0mm with 2 Magnets: #938-1210/FK342 Nozzle Ø 1.0mm with 4 Magnets: #938-1210/FK344

The values specified must be considered as approximate values.

The number of pulses per litre may differ depending on medium and installation. We recommend to calibrate the number of pulses per litre in line with the complete installation.


MEASUREMENT TIPS


- Ensure that there is no fast-pulsatory movement of the media
- Ensure that there are no reverse pressure surges
- Ensure that there is no air in the system
- Keep the pressure loss as small as possible
- · Note the mounting position of the flowmeter
- Min/max flow should be in the linear range of the selected flowmeter
- Clean the system at appropriate intervals
- · Avoid electrical current peaks
- Incorrect cabling of power supply +, signal and ground will destroy the flowmeter
- Do not mechanically load electrical contacts
- Avoid moisture on the electrical contacts
- Avoid stray pick-up via the cable (Do not lay cables in parallel with high current loads)

We reserve the right to make modifications in the interests of technical progress

Version 02 FHKU G1/4" High Flow #938-12xx/xK34x GB Seite 4-10

Measurement Curve FHKU G1/4" Ø1.20mm High Flow





Medium: Water / max. Pressure: 3.3 bar

Number of magnets	Nozzle size	Pulses/ Litres	Gramm/Puls	Recommended min. flow rate at [I/min]	Flow rate at 1900 rpm [l/ min]
2	Ø 1.20 mm	1787	0.56	0.031	1.06
4	Ø 1.20 mm	3574	0.28	0.031	1.06

Part number:

Nozzle Ø 1.2mm with 2 Magnets: #938-1212/FK342 Nozzle Ø 1.2mm with 4 Magnets: #938-1212/FK344

The values specified must be considered as approximate values.

The number of pulses per litre may differ depending on medium and installation. We recommend to calibrate the number of pulses per litre in line with the complete installation.


MEASUREMENT TIPS


- Ensure that there is no fast-pulsatory movement of the media
- Ensure that there are no reverse pressure surges
- Ensure that there is no air in the system
- Keep the pressure loss as small as possible
- · Note the mounting position of the flowmeter
- Min/max flow should be in the linear range of the selected flowmeter
- Clean the system at appropriate intervals
- · Avoid electrical current peaks
- Incorrect cabling of power supply +, signal and ground will destroy the flowmeter
- Do not mechanically load electrical contacts
- Avoid moisture on the electrical contacts
- Avoid stray pick-up via the cable (Do not lay cables in parallel with high current loads)

We reserve the right to make modifications in the interests of technical progress

Version 02 FHKU G1/4" High Flow #938-12xx/xK34x GB Seite 5-10

Measurement Curve FHKU G1/4" Ø2.00mm High Flow





Medium: Water / max. Pressure: 3.3 bar

Number of magnets	Nozzle size	Pulses/ Litres	Gramm/Puls		Flow rate at 1900 rpm [l/ min]
2	Ø 2.00 mm	1013	0.98	0.110	1.87
4	Ø 2.00 mm	2026	0.49	0.110	1.87

Part number:

Nozzle Ø 2.0mm with 2 Magnets: #938-1220/FK342 Nozzle Ø 2.0mm with 4 Magnets: #938-1220/FK344

The values specified must be considered as approximate values.

The number of pulses per litre may differ depending on medium and installation.

We recommend to calibrate the number of pulses per litre in line with the complete installation.


MEASUREMENT TIPS


- Ensure that there is no fast-pulsatory movement of the media
- Ensure that there are no reverse pressure surges
- Ensure that there is no air in the system
- Keep the pressure loss as small as possible
- · Note the mounting position of the flowmeter
- Min/max flow should be in the linear range of the selected flowmeter
- Clean the system at appropriate intervals
- · Avoid electrical current peaks
- Incorrect cabling of power supply +, signal and ground will destroy the flowmeter
- Do not mechanically load electrical contacts
- Avoid moisture on the electrical contacts
- Avoid stray pick-up via the cable (Do not lay cables in parallel with high current loads)

We reserve the right to make modifications in the interests of technical progress

Version 02 FHKU G1/4" High Flow #938-12xx/xK34x GB Seite 6-10

Measurement Curve FHKU G1/4" Ø2.50mm High Flow





Medium: Water / max. Pressure: 3.3 bar

Number of magnets	Nozzle size	Pulses/ Litres	Gramm/Puls	Recommended min. flow rate at [I/min]	Flow rate at 1900 rpm [l/ min]
2	Ø 2.50 mm	754	1.32	0.067	2.52
4	Ø 2.50 mm	1508	0.66	0.067	2.52

Part number:

Nozzle Ø 2.5mm with 2 Magnets: #938-1225/FK342 Nozzle Ø 2.5mm with 4 Magnets: #938-1225/FK344

The values specified must be considered as approximate values.

The number of pulses per litre may differ depending on medium and installation. We recommend to calibrate the number of pulses per litre in line with the complete installation.


MEASUREMENT TIPS


- Ensure that there is no fast-pulsatory movement of the media
- Ensure that there are no reverse pressure surges
- Ensure that there is no air in the system
- Keep the pressure loss as small as possible
- · Note the mounting position of the flowmeter
- Min/max flow should be in the linear range of the selected flowmeter
- Clean the system at appropriate intervals
- · Avoid electrical current peaks
- Incorrect cabling of power supply +, signal and ground will destroy the flowmeter
- Do not mechanically load electrical contacts
- Avoid moisture on the electrical contacts
- Avoid stray pick-up via the cable (Do not lay cables in parallel with high current loads)

We reserve the right to make modifications in the interests of technical progress

Version 02 FHKU G1/4" High Flow #938-12xx/xK34x GB Seite 7-10

Measurement Curve FHKU G1/4" Ø3.00mm High Flow





Medium: Water / max. Pressure: 3.3 bar

Number of magnets	Nozzle size	Pulses/ Litres	Gramm/Puls	Recommended min. flow rate at [I/min]	Flow rate at 1900 rpm [l/ min]
2	Ø 3.00 mm	527	1.74	0.130	3.32
4	Ø 3.00 mm	1054	0.87	0.130	3.32

Part number:

Nozzle Ø 3.0mm with 2 Magnets: #938-1230/K342 Nozzle Ø 3.0mm with 4 Magnets: #938-1230/K344

The values specified must be considered as approximate values.

The number of pulses per litre may differ depending on medium and installation. We recommend to calibrate the number of pulses per litre in line with the complete installation.


MEASUREMENT TIPS


- Ensure that there is no fast-pulsatory movement of the media
- Ensure that there are no reverse pressure surges
- Ensure that there is no air in the system
- Keep the pressure loss as small as possible
- · Note the mounting position of the flowmeter
- Min/max flow should be in the linear range of the selected flowmeter
- Clean the system at appropriate intervals
- · Avoid electrical current peaks
- Incorrect cabling of power supply +, signal and ground will destroy the flowmeter
- Do not mechanically load electrical contacts
- Avoid moisture on the electrical contacts
- Avoid stray pick-up via the cable (Do not lay cables in parallel with high current loads)

We reserve the right to make modifications in the interests of technical progress

Version 02 FHKU G1/4" High Flow #938-12xx/xK34x GB Seite 8-10

Measurement Curve FHKU G1/4" Ø4.00mm High Flow





Medium: Water / max. Pressure: 3.3 bar

Number of magnets	Nozzle size	Pulses/ Litres	Gramm/Puls		Flow rate at 1900 rpm [l/ min]
2	Ø 4.00 mm	382	2.61	0.113	4.97
4	Ø 4.00 mm	764	1.30	0.113	4.97

Part number:

Nozzle Ø 4.0mm with 2 Magnets: #938-1240/K342 Nozzle Ø 4.0mm with 4 Magnets: #938-1240/K344

The values specified must be considered as approximate values.

The number of pulses per litre may differ depending on medium and installation. We recommend to calibrate the number of pulses per litre in line with the complete installation.


MEASUREMENT TIPS


- Ensure that there is no fast-pulsatory movement of the media
- Ensure that there are no reverse pressure surges
- Ensure that there is no air in the system
- Keep the pressure loss as small as possible
- · Note the mounting position of the flowmeter
- Min/max flow should be in the linear range of the selected flowmeter
- Clean the system at appropriate intervals
- · Avoid electrical current peaks
- Incorrect cabling of power supply +, signal and ground will destroy the flowmeter
- Do not mechanically load electrical contacts
- Avoid moisture on the electrical contacts
- Avoid stray pick-up via the cable (Do not lay cables in parallel with high current loads)

We reserve the right to make modifications in the interests of technical progress

Version 02 FHKU G1/4" High Flow #938-12xx/xK34x GB Seite 9-10

Measurement Curve FHKU G1/4" Ø5.60mm High Flow





Medium: Water / max. Pressure: 3.3 bar

Number of magnets	Nozzle size	Pulses/ Litres	Gramm/Puls	Recommended min. flow rate at [I/min]	Flow rate at 1900 rpm [l/ min]
2	Ø 5.60 mm	256	3.90	0.180	7.42
4	Ø 5.60 mm	512	1.95	0.180	7.42

Part number:

Nozzle Ø 5.6mm with 2 Magnets: #938-1256/K342 Nozzle Ø 5.6mm with 4 Magnets: #938-1256/K344

The values specified must be considered as approximate values.

The number of pulses per litre may differ depending on medium and installation. We recommend to calibrate the number of pulses per litre in line with the complete installation.

MEASUREMENT TIPS

- Ensure that there is no fast-pulsatory movement of the media
- Ensure that there are no reverse pressure surges
- Ensure that there is no air in the system
- Keep the pressure loss as small as possible
- · Note the mounting position of the flowmeter
- Min/max flow should be in the linear range of the selected flowmeter
- Clean the system at appropriate intervals
- · Avoid electrical current peaks
- Incorrect cabling of power supply +, signal and ground will destroy the flowmeter
- Do not mechanically load electrical contacts
- Avoid moisture on the electrical contacts
- Avoid stray pick-up via the cable (Do not lay cables in parallel with high current loads)

We reserve the right to make modifications in the interests of technical progress

Version 02 FHKU G1/4" High Flow #938-12xx/xK34x GB Seite 10-10